

WHAT'S INCLUDED

- Filter Cartridge (Café - SC2-SR / SC2-MR)
(Steam - SS2-MR)
(Taste - ST2-MR)
(Taste Phos. - STP2-MR)
- Filter Head Kit (SH2-KIT - Includes bracket and fittings)

INITIAL HEAD INSTALLATION

- Select a suitable mounting position for the head (cartridge can be laid down if needed).
- Drill holes to accommodate rawlplugs.
- Inset rawlplugs and screws ready for bracket installation.
- Slide bracket over screws and tighten into place.
- Add preferred fittings to head and secure with locking clips.
- Locate head into lugs either side of the bracket, clicking into place.
- Isolate water supply (this is usually $\frac{3}{8}$ ")
- Insert $\frac{3}{8}$ " pipework into push fittings connections and secure with collet clips. If threaded pipework is required, the head comes as standard with $\frac{3}{8}$ " BSPM thread.

CARTRIDGE INSTALLATION

- Check the cartridge prior to installation, it should have the tamper free red cap located, ready for fitting.
- Fill out the "date change" part of the label with the proposed next change date.
- Remove the red cap, ready for fitting.
- Push the head of the cartridge up into the head and twist clockwise fully until it clicks into place.
- Turn on the water.
- Take the flush tube and insert into a bucket or vessel and flush water until it runs clean, this normally takes around 10 seconds. This is done by moving the flush lever on the top of the head to flush position.
- Turn the bypass setting to suit local water quality and desired water quality. (See Cartridge Capacity chart in datasheet).
- Return the flush lever to service position and you are ready to go!



(Head with fittings on.)



(Complete unit fitted in cupboard.)